

The MATE interface is available in two main sizes:

- Small
- Large

The device also incorporates some adjustment elements in order to adapt to the different body sizes of the users and facilitate ease of use.

The instructions for a correct wearing are indicated at [par. 3.2 Wearing procedure on page 28](#).

The same instructions for use must be applied to both sizes.

Please contact Comau to understand which size is most suitable for your needs. As an indicative reference, it is possible to consult the following table:

Tab. 2.1 - Indicative references for choosing the appropriate size

| | Size for braces | pHRi size |
|-------|-----------------------------|-----------|
| Men | 34 - 38 (US) / 44 - 48 (EU) | S |
| | 40 - 50 (US) / 50 - 60 (EU) | L |
| Women | 0 - 12(US) / 36 - 48 (EU) | S |
| | 14 - 16 (US) / 50 - 52 (EU) | L |

2.1.2 Passive degrees of freedom (pDOFs)

Fig. 2.3 - Passive degrees of freedom (pDOFs)



1. Horizontal axis hinge
2. Back elastics
3. Vertical axis hinge
4. Horizontal axis rear sliding elements
5. Arm supports sliding cuffs

Passive degrees of freedom ([Fig. 2.3](#)) allow the correct wearing of MATE and its adaptation to different body sizes. They also allow the user to move freely once the device is worn.